Clearlight®

Glass Alignment Guide

!! IMPORTANT

Please refer to our installation manual that you received with your unit on page 11 in addition to this guide.

1

Use provided hardware and allen wrench to connect the glass panels.

If panels are uneven you will need to use a level and shims to adjust the glass panels so the door will close properly and connect with the magnet at the bottom of the panel.



2

Make sure unit is level by as indicated in the photo above.



Glass Alignment

Clearlight®

3

4

It may be necessary to shim the front and the sides of the unit in order to get the panels to align.

This issue is caused when the sauna is on an uneven surface.

It is also important to make sure all the weather stripping has been properly installed with no kinks and that is flush with the edge of the glass.







For more questions or concerns, call 800-798-1779 + option 2 for service

Or feel free to email service@infraredsauna.com