

# Clearlight®

## How To Change a Sauna Light

### **What You will Need:**

- Flat Head Screw Driver (Optional)

**Important: Unplug the Sauna before starting. Light fixtures might look different depending on location and Sauna model, but each one is changed out the same way.**

**Very Important: All Sauna light fixture use metal springs to keep the fixture in place, these springs act like a mouse trap springing back with harmful force if not careful.**



**Step 1:** Gently pull down the fixture from the outer metal fixture ring. As the fixture is being pulled down the springs should become noticeable. Once the springs are located make sure to pull down the fixture from the opposite sides of the springs.

**Step 2:** When pulled out, the fixture will still be attached by a black or white molex connector. Disconnect the molex connector from the fixture. Take the new fixture and attach it to the same molex connector the original fixture was attached to. Make sure molex connector is firmly connected.

**Step 2a:** If you have a Sanctuary model Sauna the light fixture will require an additional step. This light fixture has an extra part, identified by a white plastic box labeled LED driver. Make sure to disconnect the old LED driver and replace it.

**Step 3:** Being just as careful as before, force the spring clips back towards each other, so they can fit inside light fixture hole. Once the spring clips are up inside the hole the fixture should easily snap back into place.

**Below are images illustrating the above process.**



How To Change a Sauna Light

## How To Change a Sauna Light

