

Clearlight®

Reservation (Reserve) Mode

1. When the sauna is on, pressing Reserve will turn off all heaters (with the blinking timer mentioned above).
2. It is okay that only the time blinks when setting the Reserve mode for your sauna (both timer and temperature blinking were from older sauna functionality).
3. Nothing else needs to be pressed after setting your desired start time...just leave the timer blinking.
4. Besides being able to set the timer hours ahead, pressing TEMP DOWN when the keypad shows one hour will bring you to minutes ("min" will be shown on the right).
5. When the Reservation timer gets to zero, it actually has one minute remaining from that point until the sauna turns on.
6. When the sauna powers on automatically from Reservation mode, the session timer will count down from your last-used regular session time.
 - In other words, if your last regular sauna session was set at 30 minutes, that's how long the sauna will remain on after it starts off of Reservation mode.