

16 - Hour Mode - Commercial Use

WHAT IS THE 16 - HOUR MODE?

Clearlight offers our commercial customers the functionality of setting their saunas to run for 16 hours!

Yes - 16 hours. Just set it to the 16 hour mode and go about your day with a preheated infrared sauna for your clients.

ACTIVATE IT HERE:

- Turn the power on at the keypad.
- Set the temperature icon, "F/C" button, to C for Celcius.
- Turn the actual temperature setting to 10 degrees Celsius.
- Hold the AUX button for 5 - 7 seconds until you hear it beep.
- Change the temperature icon back to F for Fahrenheit.
- Set the actual temperature to 175 degrees Fahrenheit to ensure that the heaters stay on.
- Wait for a minute or two, and the heaters will turn on.
- The 16 hour mode is now activated. However the heaters will still turn off if the temperature reaches the inside temperature of the sauna. So keep the temperature high!
- The time icons, up/down, will still work, but when it reaches zero, the heaters will NOT shut off.
- To stop the 16 hour mode; simply press the power icon to turn the sauna off.
- To restart the 16 hour mode; go through the steps listed above.
- To do a quick test to see if it is set to the 16 hour mode; set the time to zero and the heaters should remain on.