



## How To Disable Bluetooth/Aux/Sound System

### **What You will Need:**

- Phillips Head Screw Driver
- Step Ladder
- Power Drill (Optional)

### **Important: Unplug the Sauna before starting.**

**Step 1:** Using the step ladder to access the roof of your Sauna, position it on the side of the Sauna where the power cord descends from.

**Step 2:** Once on you have access to the roof you will need to unscrew the roof hatch that corresponds with the location of the Bluetooth circuit board. The Bluetooth circuit board is located under the same hatch where you will find the metal silver power supply box. To find the correct hatch look for a mesh cut out on the roof wood. Unscrew the corresponding entire hatch screws to gain access.

**Step 3:** Once unscrewed lift the hatch. You will see what might seem like a confusing set of wires and electrical parts. The Bluetooth circuit board will be near the large metal silver power supply box (not be inside the box). Look for the Bluetooth circuit board located on a yellow textured board screwed onto the roof.

**Step 4:** Once you have located the Bluetooth circuit board it is time to disable it. This can be done one of two ways. Depending on the age of your Sauna the Bluetooth circuit board has two designs. If you have the older design the only way to disable is unconnect the two-pin black & white molex connector. This controls the power to the unit. On the newer Bluetooth circuit board there is an very small switch, simply switch it to off position. Now the circuit board is disabled.

**Step 5:** Lastly, while you still have access to the roof plug your Sauna back into the outlet and turn it on to test if the Bluetooth is disabled. Then screw the roof hatch back down.



## How To Disable Bluetooth/Aux/Sound System

Below are images illustrating the above process.

**Important:** This circuit board controls all audio functions on your Sauna, by disabling it you will no longer have the ability to play any audio through the Sauna speakers.




## How To Disable Bluetooth/Aux/Sound System






## How To Disable Bluetooth/Aux/Sound System



Latest Bluetooth Circuit Board

## How To Disable Bluetooth/Aux/Sound System



Older Bluetooth Circuit Board

**Important: This circuit board controls all audio functions on your Sauna, by disabling it you will no longer have the ability to play any audio through the Sauna speakers.**